

Алматы (7273)495-231
 Ангарск (3955)60-70-56
 Архангельск (8182)63-90-72
 Астрахань (8512)99-46-04
 Барнаул (3852)73-04-60
 Белгород (4722)40-23-64
 Благовещенск (4162)22-76-07
 Брянск (4832)59-03-52
 Владивосток (423)249-28-31
 Владикавказ (8672)28-90-48
 Владимир (4922) 49-43-18
 Волгоград (844)278-03-48
 Вологда (8172)26-41-59
 Воронеж (473)204-51-73
 Екатеринбург (343)384-55-89

Ижевск (3412)26-03-58
 Иваново (4932)77-34-06
 Иркутск (395)279-98-46
 Казань (843)206-01-48
 Калининград (4012)72-03-81
 Калуга (4842)92-23-67
 Кемерово (3842)65-04-62
 Киров (8332)68-02-04
 Коломна (4966)23-41-49
 Кострома (4942)77-07-48
 Краснодар (861)203-40-90
 Красноярск (391)204-63-61
 Курск (4712)77-13-04
 Курган (3522)50-90-47
 Липецк (4742)52-20-81

Киргизия (996)312-96-26-47

Магнитогорск (3519)55-03-13
 Москва (495)268-04-70
 Мурманск (8152)59-64-93
 Набережные Челны (8552)20-53-41
 Нижний Новгород (831)429-08-12
 Новокузнецк (3843)20-46-81
 Ноябрьск (3496)41-32-12
 Новосибирск (383)227-86-73
 Ноябрьск (3496)41-32-12
 Омск (3812)21-46-40
 Орел (4862)44-53-42
 Оренбург (3532)37-68-04
 Пенза (8412)22-31-16
 Петрозаводск (8142)55-98-37
 Псков (8112)59-10-37

Россия (495)268-04-70

Пермь (342)205-81-47
 Ростов-на-Дону (863)308-18-15
 Рязань (4912)46-61-64
 Самара (846)206-03-16
 Саранск (8342)22-96-24
 Санкт-Петербург (812)309-46-40
 Саратов (845)249-38-78
 Севастополь (8692)22-31-93
 Симферополь (3652)67-13-56
 Смоленск (4812)29-41-54
 Сочи (862)225-72-31
 Ставрополь (8652)20-65-13
 Сыктывкар (8212)25-95-17
 Сургут (3462)77-98-35
 Тамбов (4752)50-40-97

Казахстан (772)734-952-31

Тверь (4822)63-31-35
 Тольятти (8482)63-91-07
 Томск (3822)98-41-53
 Тула (4872)33-79-87
 Тюмень (3452)66-21-18
 Улан-Удэ (3012)59-97-51
 Ульяновск (8422)24-23-59
 Уфа (347)229-48-12
 Хабаровск (4212)92-98-04
 Чебоксары (8352)28-53-07
 Челябинск (351)202-03-61
 Череповец (8202)49-02-64
 Чита (3022)38-34-83
 Якутск (4112)23-90-97
 Ярославль (4852)69-52-93

<https://follett.nt-rt.ru> || fti@nt-rt.ru

Аксессуары для льдогенераторов Chewblet


Chewblet® ice machine accessories



Shown with Horizon Elite™ ice machine

Ice machine stand

Stand for Horizon Elite™ and Maestro Plus™ ice machines with RIDE® remote ice delivery equipment to elevate ice machines 6.80" (17.3 cm) to 8.30" (21.1 cm) above the floor.



Model	Configuration: (A/W) – air- or water-cooled (R/N) – with or without remote condenser	Item number
414	self-contained (A)	AFR400STND
425	self-contained (A/W)	AFR400STND
710	self-contained (A)	00997080
1010	self-contained (A/W)	01085463
	remote (R/N)	00997080
1410	self-contained (A/W)	01085463
	remote (R/N)	00997080
1412	remote (R/K)	00997080
1810	remote (R/N)	00997080
2110	remote (R/N)	00997080

Model	W1	D1	H1	H2
414/425 (A/W)	18.70" (47.5 cm)	22.70" (57.7 cm) ¹	23.80" (60.5 cm)	6.80" (17.3 cm)
710 A	22.70" (57.7 cm)	24.50" (62.2 cm)	28.00" (71.1 cm)	6.80" (17.3 cm)
1010/1410 (A/W)	29.15" (74.0 cm)	23.25" (59.1 cm)	29.30" (74.4 cm)	6.80" (17.3 cm)
1010/1410 (R/N) 1412 (R/K)	22.70" (57.7 cm)	22.50" (57.2 cm)	28.00" (71.1 cm)	6.80" (17.3 cm)
1810/2110 (R/N)	22.70" (57.7 cm)	23.70" (60.2 cm)	29.30" (74.4 cm)	6.80" (17.3 cm)


¹ Depth includes 1.90" (4.83 cm) shroud and gasket to mate condenser to interior of cabinet for adequate air intake.



Shown with Horizon Elite ice machine

Wall mount bracket

Wall mount bracket for ice machines with RIDE remote ice delivery equipment conserves floor space. Allows ice machine to be located away from customer areas.



Model	Configuration: (A/W) – air- or water-cooled (R/N) – with or without remote condenser	Item number
414	self-contained (A/W)	AFWALLMTBRKT
425	self-contained (A/W)	AFWALLMTBRKT
710	self-contained (A)	00997098
1010	self-contained (A/W)	01085455
	remote (R/N)	00997098
1410	self-contained (A/W)	01085455
	remote (R/N)	00997098
1412	remote (R/K)	00997080
1810	remote (R/N)	00997098
2110	remote (R/N)	00997098

Model	W1	D1	H1 ¹
414/425² (A/W)	26.20" (66.5 cm)	20.20" (51.3 cm)	19.40" (49.3 cm)
1010/1410 (A/W)	30.50" (77.5 cm)	25.50" (64.8 cm)	23.50" (59.7 cm)
710 (A) 1010/1410/1810/2110 (R/N) 1412 (R/K)	23.00" (58.4 cm)	25.50" (64.8 cm)	22.50" (57.2 cm)

¹ Height of bracket and ice machine.

² 414 and 425 (Maestro Plus) oriented with utilities to left side on wall mount bracket.



Line set

Line set for connecting Horizon Elite evaporator units to their remote condensing unit. Lines are cleaned and capped without a pre-charge of refrigerant. Connections must be brazed (no quick connect).

Model	Line size	Length	Item number
1010 and 1410 remote (R/N)	3/8" liquid, 5/8" suction (insulated)	35 ft (11 m)	00193227
1412 (R/K) 1810 and 2110 remote (R/N)	3/8" liquid, 7/8" suction (insulated)	35 ft (11 m)	00977785
1010 and 1410 remote (R/N)	5/8" liquid, 7/8" suction (insulated)	50 ft (15 m)	01262328



Timer


Timer to control one or two Horizon Elite ice machines.

Model	Item number
710, 1010, 1410, 1412, 1810, 2110	00967265




Slide-out stand


Slide-out accessory for Maestro Plus ice machines with RIDE technology allows easy access for service and cleaning without disconnecting utilities. Includes front leg to support ice machine.



Front view



Side view



Model	Item number
MCD425AVS, MCD425WVS, MCD425AHS, MCD425WHS	01068477 ¹
MCE414AHS, MCE414ABS, MCE414AVS	01336494

¹ Compatible with AFR400STND accessory.

Алматы (7273)495-231
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922)49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Ижевск (3412)26-03-58
Иваново (4932)77-34-06
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Колмна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81

Киргизия (996)312-96-26-47

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Ноябрьск (3496)41-32-12
Новосибирск (383)227-86-73
Ноябрьск (3496)41-32-12
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37

Россия (495)268-04-70

Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Саранск (8342)22-96-24
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сыктывкар (8212)25-95-17
Сургут (3462)77-98-35
Тамбов (4752)50-40-97

Казахстан (772)734-952-31

Тверь (4822)63-31-35
Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Улан-Удэ (3012)59-97-51
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

<https://follett.nt-rt.ru> || fti@nt-rt.ru